


# CLARINET PARTS CHART | BUNDLES



- 01** CLBD01 - Mouth Piece Cover
- 02** CLBD02 - Mouth Piece
- 03** CLBD03 - Reed
- 04** CLBD04 - Reed Release Key
- 05** CLBD05 - Reed Key Ring
- 06** CLBD06 - Barrel
- 07** CLBD07 - Upper Joint

- 08** CLBD08 - A Key
- 09** CLBD09 - E $\flat$ -B $\flat$  Auxiliary Key
- 10** CLBD10 - Top G $\sharp$  Key
- 11** CLBD11 - Thumb Key
- 12** CLBD12 - E $\flat$ -B $\flat$  Trill Key
- 13** CLBD13 - Register Key
- 14** CLBD14 - C $\sharp$ -G $\sharp$  Key

- 15** CLBD15 - F $\sharp$  Ring Key
- 16** CLBD16 - A-D Upper Bridge Key
- 17** CLBD17 - Lower Joint
- 18** CLBD18 - A $\flat$ -E $\flat$  Key
- 19** CLBD19 - Low F-C Key
- 20** CLBD20 - F-C Lever
- 21** CLBD21 - E-B Lever

- 22** CLBD22 - F $\sharp$ -C $\sharp$  Lever
- 23** CLBD23 - B-F $\sharp$  Key
- 24** CLBD24 - F $\sharp$ -C $\sharp$  Key
- 25** CLBD25 - Low E-B Key
- 26** CLBD26 - Low Bridge Key
- 27** CLBD27 - Bell